

size:95*208mm
材质: 128铜板纸
正反面印刷



Quick Start Guide

Model RCx-1000

It's as easy as 1,2,3



Setup

- Apply AC adapter to RCx-1000 (Optional for remote control).
- Connect RCx-1000 to the telephone jack

Pairing the Remote

- Press and hold **FLASH** button until it “beeps” and indicator flashes.
- Press the remote button until both remote and RCx-1000 beep.
- Pairing is complete.

Programming Memory Locations

- Press **PROGRAM** button once.
- Dial the telephone number using the keypad (Maximum 32 digits).
- Press any one touch memory button to save. (indicator will be lit) Press once to save at 1st location, press twice to save in 2nd location.
- RCx-1000 will make a “beep” sound to confirm. The indicator light will go off.
- Repeat the above steps to set other memory locations.

To Answer Calls

- Press the remote control button once. **OR**
- Press the RCx-1000 **ON/OFF** button. **OR**
- Press the optional accessory switch once (if attached to the RCx-1000 or the remote control). **OR**
- If voice activation function is enabled, say "HELLO" loudly with an elongated tempo towards its microphone during the silence period between rings.

To Make Calls

- With Remote Control
 - Press remote button once. RCx-1000 will begin scanning all memory locations.
 - Press remove button again to select desired memory location
 - RCx-1000 will turn on and dial the stored number.
- With Remote Control (**SCAN** function off)
 - Press remote button once.
 - RCx-1000 will turn on and dial the memory **M1** (first location) stored number
- With **SCAN** Button
 - Press **SCAN** button once. RCx-1000 will start scanning all memory locations.
 - Press **SCAN** button again to select desired memory location.
 - RCx-1000 will turn on and dial the stored number.
- Manual Dialing
 - Press the RCx-1000 **ON/OFF** button once, and wait for the dial tone.
 - Dial the telephone numbers using the keypad.
- To End A Call
 - Press the RCx-1000 **ON/OFF** button **OR**
 - Press the remote control button once.

△ 06-13-16

Need Help? Call Toll-free Help Line:
866-376-9271 (8AM - 5PM PST, M-F)

14731 Carmenita Road, Norwalk, CA 90650
www.sereneginnovations.com